Auto Reset / Battery Backup / Auxiliary Contacts

Leading Edge Design



Alarm Systems

Early Warning - Notification While You're Away - Power Outages - Expandable

B US

A standard Versa'larm[™] - Sump Alarm includes an alarm panel and a WaterSpotter[™] Probe sensor. The sensor may be up to 2,500 feet from the Versa'larm. Receive immediate notification of threatening water levels by connecting an Auto Dialer to the Versa'larm. The Auto Dialer will call four contact numbers when an alarm occurs. Install a standard 9 volt battery to ensure the system will operate during power outages or accidental unplugging of the unit. Once the standard Versa'larm - Sump Alarm is installed, add accessories to create a total "Home Protection System." Add up to six WaterSpotters[™] for complete property protection. Add the low temperature switch option with an Auto Dialer and get Furnace Failure notification while away from home.

> WaterSpotter™ Probe - mounts in sumps —

> > Sump

Leak Detection System


Stand-Alone Alarm

Install the standard Versa'larm[™] - Sump Alarm

(Includes one Versa'larmTM and one WaterSpotterTM Probe)

Typical Applications:

A standard alarm may be all that you need. Expand at any time if you want additional coverage, simply add accessories for customized protection.




Float Switches

Leading Edge Control Products

Control Panels

Auto Reset / Battery Backup / Auxiliary Contacts



- 7006 Auto Dialer: one common message used for all sensors
- 7019 Auto Dialer: two different messages, one for water sensor and one for furnace fail



Leading Edge Control Products

CS1002A